


∩exus M

Quick Start Guide


Contents

	Specification	p.01
	Panel Removal	p.02
*	Front Panel I/O Connections	p.03
*	Component List	p.04
	Motherboard Installations	p.05
	SSD Installation	p.06
	GPU & PSU Installation	p.07
	Cable Management Area	p.08
	CPU Cooler / Fan Installation	p.09
	Package Contents & Warranty	p.10



Specifications

Туре	Specification
Motherboard Support	ITX, mATX
Dimensions	340(L) x 205(W) x 413(H) mm
3.5" HDD Drive Bay	2
2.5" SSD Drive Bay	2
Expansion Slots	4
Maximum GPU Length	330mm
Maximum CPU Cooler Height	160mm



Front Panel I/O Connections



BUTTONS AND ACTIVITY LIGHTS

These cables are connected to the motherboard for the power button (power sw), reset button, HDD LED, and power LED (P+ / P-).



HD AUDIO

This connector attaches to your sound card or motherboard and is used to provide the front panel mic input and headphone output.




USB 3.0 CONNECTOR

This cable connects to the USB 3.0 header on the motherboard to enable the front USB 3.0 port.

Component List

	VISUAL	ITEM	QTY	APPLICATION
A	•	Motherboard & SSD screw	12	Motherboard and 2.5 hard drive installation
В		Motherboard standoff	2	Motherboard installation
С		HDD mount screw	6	3.5 hard drive installation
D		PSU & Rear expansion slot screw	6	Power supply installation Mounting of GPU and other expansion cards


Motherboard Installation





SSD / HDD Installation


SSD / HDD Drive Installation




GPU & PSU Installation

Graphics Processing Unit and other expansion cards • GPU and other expansion cards Screw (Type D)


Power Supply Unit Installation



Cable Management Area



CPU Cooler / Fan Installation



Package Contents

- 1 x TECWARE NEXUS AIR M Case (w/ Orbis Controller Hub)
- · 1 x Orbis Remote
- 1 x Bag of Screws

Warranty

• 1 Year. Please contact your local distributor for support.



www.tecware.co