



MIRAGE

RGB LIQUID COOLER

Quick Start Guide

Contents

◆ Components List	p.01
◆ Radiator/Fan Installation	p.02
◆ Thermal Compound Application	p.03
◆ INTEL Installation	p.04
◆ AMD Installation	p.05
◆ Controller Installation	p.06-07

Components List

A Intel Mounting Bracket



x2

B AMD Mounting Bracket



x2

C Mounting Bracket Screw



x5

D Radiator Fan Screw



MIRAGE 120 **x4**
MIRAGE 240 **x8**
MIRAGE 360 **x12**

E Intel Mounting Backplate



x1

F Radiator Mounting Screw




MIRAGE 120 **x4**
MIRAGE 240 **x8**
MIRAGE 360 **x12**

G Thermal Paste



x1


Radiator/Fan Installation



1. Install Fans onto Radiator using (D) Screws. (Pre-installed)
2. Install Radiator onto case using (F) Screws.


Thermal Compound Application

Step 1:




Remove protective film from copper base.

Step 2:




Apply thermal compound (included) onto the centre of the CPU.


INTEL Installation



AMD Installation




Controller Installation



Controller Installation

STEP 1 : Connect Pump's Power and ARGB connectors to the hub.



STEP 2 : Connect Fans' Power and ARGB connectors to the hub.
Connect other ARGB devices. (optional)

STEP 3 : Connect Controller's SATA Power to PSU.
Connect ARGB header to motherboard. (if applicable)
Connect Case LED/Reset Button connector.

Note : Hold LED / reset button for 3sec to toggle between onboard controller mode and motherboard sync mode.



www.tecware.co