


Nexus M2

Quick Start Guide

Contents


\&	Specification	p.01
\$	Panel Removal	p.02
\$	Front Panel I/O Connections	p.03
\&	Component List	p.04
\&	Motherboard Installations	p.05
\&	SSD Installation	p.06
\$	GPU & PSU Installation	p.07
\&	Cable Management Area	p.08
\rightarrow	CPU Cooler / Fan Installation	p.09
\&	Package Contents & Warranty	p.10



Specifications

Туре	Specification
Motherboard Support	mITX, mATX
Dimensions	350(L) x 200(W) x 390(H) mm
3.5" HDD Drive Bay	2
2.5" SSD Drive Bay	1
Expansion Slots	4
Maximum GPU Length	300mm
Maximum PSU Length	180mm
Maximum CPU Cooler Height	165mm

Panel Removal



Open the front cover by pulling outwards to the right.

Front Panel I/O Connections



BUTTONS AND ACTIVITY LIGHTS

These cables are connected to the motherboard for the power button (power sw), reset button, HDD LED, and power LED (P+ / P-).



HD AUDIO

This connector attaches to your sound card or motherboard and is used to provide the front panel mic input and headphone output.




USB 3.0 CONNECTOR

This cable connects to the USB 3.0 header on the motherboard to enable the front USB 3.0 port.

Component List

	VISUAL	ITEM	QTY	APPLICATION
A	©	Motherboard & SSD screw	12	Motherboard and 2.5 hard drive installation
В		Motherboard standoff	2	Motherboard installation
С		HDD mount screw	4	3.5 hard drive installation
D		PSU & Rear expansion slot screw	6	Power supply installation Mounting of GPU and other expansion cards
E		Cable tie	5	Cable management


Motherboard Installation






SSD / HDD Installation

SSD / HDD Drive Installation




GPU & PSU Installation


Graphics Processing Unit and other expansion cards




Power Supply Unit Installation



Cable Management Area



CPU Cooler / Fan Installation



Package Contents

- 1 x TECWARE NEXUS M2 Case
- · 1 x Bag of Screws

Warranty

• 1 Year. Please contact your local distributor for support.



www.tecware.co