




SPECTRE

MECHANICAL GAMING KEYBOARD

Quick Start Guide

Key Features




- | | | | |
|-------------------|-----------------------|---------------------------------|----------------------------------|
| ① Media Player | ⑧ Forward | ⑮ Windows Lock Indicator | ⑳ Lighting Mode 2 |
| ② Volume Decrease | ⑨ Email | ⑯ Custom Lighting Mode | ㉑ Lighting Mode 3 |
| ③ Volume Increase | ⑩ Home Page | ⑰ LED Lighting Speed Decrease | ㉒ Lighting Mode 4 |
| ④ Volume Mute | ⑪ My Computer | ⑱ LED Lighting Speed Increase | ㉓ Lighting Mode 5 |
| ⑤ Stop | ⑫ Calculator | ㉒ Lighting Mode 1 | ㉔ Lighting Mode 6 |
| ⑥ Rewind | ⑬ Num Lock Indicator | ㉓ Brightness Increase | ㉕ Brightness Decrease |
| ⑦ Play / Pause | ⑭ Caps Lock Indicator | ㉔ LED Lighting Direction - Left | ㉖ LED Lighting Direction - Right |

Multimedia Function

Media Player



Volume Decrease



Volume Increase




Volume Mute




Stop




Rewind



Play / Pause



Forward




Email



Home Page




My Computer



Calculator



Custom Lighting Mode




Brightness Increase




Brightness Decrease




Windows Lock



LED Lighting Speed Decrease



LED Lighting Speed Increase



LED Lighting Direction - Left




LED Lighting Direction - Right



Various LED modes can be triggered by Fn + Mode Keys



- ① Breathing - Cycle Color
- ② Breathing - Fixed Color
- ③ Fixed Color



- ① Reactive - Ripple
- ② Reactive - Single
- ③ Reactive - Horizontal



- ① Sine Wave
- ② Vortex
- ③ Rain Drops



- ① Horizontal Wave
- ② Pulse Wave
- ③ Hurricane



- ① Vertical Wave
- ② Waterfall
- ③ Swirl



- ① Diagonal Wave
- ② Fixed Color - Intensity
- ③ Ripple

104 Different LED Colors can be triggered by Fn + Space Bar

Simply press on the key with your preferred color.
Selecting Space Bar key will give you rainbow mode.

Custom Lighting Mode

- STEP 1 :** Press **Fn + ~** once to activate.
- STEP 2 :** Press **Fn + ~** again to start custom mode.
- STEP 3 :** Press each key until you get your desired color.
- STEP 4 :** Press **Fn + ~** again to save.

Package Contents

- TECWARE SPECTRE RGB
- Spare Mechanical Switch x 4
- Keycap Puller x 1
- Quick Start Guide
- Switch Puller x 1

System Requirements

- PC with USB port
- Windows XP/7/8/10

Installation

- Plug your TECWARE SPECTRE RGB into the USB port of your PC. *No driver installation is required for this product, the operating system should auto detect the keyboard when you plug it into your computer.*

Warranty

- 1 Year. Please contact your local distributor for support.

Spare Mechanical Switch Kit

There might be occasions where a mechanical switch might fail. Please refer to our website at www.tecware.co for instructions on how to easily replace the faulty switch on your keyboard.



www.tecware.co